

STATEMENT OF WORK

IRVHAFL Autoclave Install Electrical Prep Work

Background

The Food and Drug Administration (FDA) Irvine Human and Animal Food Laboratory (IRVHAFL) has four large built-in autoclaves that are aging and need replacements. A contract was initiated to purchase and install four new autoclaves, as well as removing and disposing of the old ones. The new units that were ordered have different electrical requirements than the old units requiring electrical work before installation.

Purpose/Scope

IRVHAFL is seeking a contractor to provide modifications to the electrical connections in the rooms that the autoclaves are housed in. This work must be completed before the new autoclaves can be fully installed and functional.

The bulk of the work required deals with a difference in amperage requirements between the new and old units housed on the second floor. The electrical panel in the room the autoclaves will be installed in does not currently have capacity to support the new machines.

Scope

The properly licensed (C-10 electrical) contractor shall perform all resources necessary to accomplish the tasks and deliverables described in this Statement of Work (SOW).

Salient Characteristics/ Service Specifications:

1. For the two autoclaves located on the first floor, wing 2:
 - De-energize and install LOTO on (2) old 733 autoclaves
 - Remove existing conduit and wire from each autoclave back to existing disconnects. Leave disconnects in place for connection to new autoclaves.
 - Install conduit, wire, and supports from existing 480-volt 200 amp disconnects to new autoclave 480-volt POC's.
 - Supply the following circuits for each new 733 autoclave equipment Power box/controls: 120-volt 15-amp circuit
 - RO water controller: 120-volt 15-amp circuit
 - RO water delivery pump: 120-volt 15-amp circuit
 - F&I new circuit breakers in existing panel to feed power box/controls, vacuum pumps, and RO water system
 - Provide updated panel schedules for panels affected by this scope of work
2. For the two autoclaves located on the second floor, wing 3:

- De-energize and install LOTO on (2) old autoclaves
- Remove existing conduit and wire from each autoclave. Conduit and wire is rated for 100 amp and new autoclaves are 150 amp
- Install EMT conduit, wire, and supports from existing panel LL22 and LL23 to supply (2) new 208-volt 150-amp 3 phase circuits for new 590 autoclaves
 - Furnish and install (2) Siemens reconditioned 3 poles 150-amp breakers in existing Siemens panel
 - F&I (2) 208-volt 200-amp Nema 1 fused disconnects with 150-amp fuses. (1) for each new autoclave
 - Supply the following circuits for each new 590 autoclave
 - Power box/controls: 120-volt 15-amp circuit
 - Vacuum pump: 208-volt 15-amp 3 phase circuit
 - RO water controller: 120-volt 15-amp circuit
 - RO water delivery pump: 120-volt 15-amp circuit
 - F&I new circuit breakers in existing panel LL23K to feed power box/controls, vacuum pumps, and RO water system
 - P touch label new disconnects and breakers with panel and circuit numbers
 - Provide updated panel schedules for panels affected by this scope of work

Records and Reports

The contractor shall provide service completion records to the POC at the time installation is complete.

Deliverables

Deliverable	Quantity	Delivery Date
Electrical work listed in the scope of this SOW.	1	Post Award

Shipping/Performance Destinations:

IRVHAFL
19701 Fairchild Rd.
Irvine, CA 92612

POC: Will be identified at time of award.

Period of Performance

The period of performance will start upon award execution. The contractor shall immediately begin performance of the Statement of Work (SOW) requirements. The new autoclave units have arrived, and immediate operation is desired.

DRAFT